Philips
Spout cover

Original
Black

CRP689



To cover the foam chamber of your SENSEO® coffee machine.

Go to the Specifications Tab to check your matching product

In the coffee spout of your SENSEO® coffee machine the coffee is collected and properly guided into your cup. This lid is meant to cover it. Detachable, so easy to clean – and when lost easily replaceable by a new one!

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense and simplicity

Spout cover
Original Black

CRP689/01

Specifications

Replaceable part

- Fits product types: HD7812/60, HD7812/61, HD7813/62, HD7812/50, HD7812/51, HD7812/55, HD7812/59, HD7810/90, HD7810/91, HD7811/92, HD7811/93, HD7811/94, HD7810/60, HD7810/61, HD7811/60, HD7811/62, HD7811/64, HD7811/65, HD7811/66

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2013-01-10

Version: 2.1.1

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com